



This RPM Cable is for standard installations which provide a “TACH” signal. The pigtail with the Green and Black wire, supplied with the cable is for connecting the Engine RPM. The Green wire connects to the tach signal, and the black to ground.

(For applications using an RPM Sensor for engine RPM, use the Custom RPM cable.)